Toyota Genuine


CD Single Adapter 08601-00349


Warning!

This CD Single Adapter is exclusively for CD changer magazines (Toyota part numbers 08601-00344, 08601-00495). Do not use it with other devices.


How to insert a disc into the adapter

● Insert the disc into the two tabs on the left side of the adapter.






② Slightly bend the tab on the right side and insert the disc.



③ Confirm that the disc is fully inserted into the three tabs.



Rotate the disc 2 to 3 times to check that it does not touch the recording side.

How to remove the disc from the adapter

❶ Remove it by following the reverse procedure of insertion.

(First, gently bend one of the tabs to remove it)

YEFM99456A